

PUSHBUTTON LEGEND

1. - POWER SWITCH.
2. - FM STEREO.
3. - FM.
4. - AM.
5. - PHONO.
6. - TAPE PLAYBACK.

ALL SWITCHES SHOWN IN OFF POSITION.

NOTES.. UNLESS OTHERWISE NOTED

1. RESISTORS ARE 1/2 WATT.
2. MULT. FACTORS: K=1000 M=1000 000.
3. ⏚ - DENOTES CONNECTION TO CHASSIS.
4. ALL VOLTAGES MEASURED TO CHASSIS IN FM STEREO POSITION EXCEPT Q4 VOLTAGES WHICH ARE MEASURED IN AM POSITION. NO SIGNAL APPLIED.
5. FM ANT. SWITCH S3 SHOWN IN INTERNAL ANT. POSITION.
6. CAPACITANCES IN MICROMICROFARADS GIVEN IN WHOLE NUMBERS. CAPACITANCES IN MICROFARADS GIVEN IN DECIMALS.

Printed in Canada